


Preparing your Phone

IOS Device Setup

(see page 7 for Android Setup)


The email address provided for testing should have receive an email labeled, “**FloLogic, Inc. has invited you to test FloLogic.**” Select the email and click the link the email provides.

You should be redirected to the page below.




The 3rd step above will list a code (in this case, “HDXMTFXT”) note this code for later.


Navigate to the link labeled “TestFlight from the App Store”.



Download and open TestFlight. Once open, you should see the prompt below.





Select "Redeem" and enter the invitation code you noted previously.



After entering the code, select “Redeem” again. This will redirect you to the FloLogic App installation. Select install.

After installation, return to the TestFlight app and open FloLogic. From there you will be redirected to the app and can use it normally.





You will receive a pop-up notification after opening the app. It is important to confirm that the version of the app you are using is Release IOS 3.46(4) or higher. If it is, you may select “Next”.



Because we are beta testing, a new account **must** be made on the Test Server.


When you open FloLogic through TestFlight, it should automatically be on the Test-Server for account registration.

Special Note:

If you already have an account for any existing valves in the App, you still must register for a new account on our Test-Server.

You may make the Login credentials the same as your original account.

After registering for a new account, confirm your identity through the confirmation email sent to the email address you registered your account with.



After confirming, navigate back to the FloLogic app and Login.



Once Finished, your phone will be prepared for the arrival and provisioning of your new Beta-Unit!

If you have the Beta Unit now, follow the steps on the "Quick Start" Guide or "Main Guide" to get your unit set-up properly.

If you've already installed the Beta Unit, please reference "Beta Provisioning" to set your device up with your Valve to begin testing.


Any valves that were previously monitored using the FloLogic app will not be available to access on the Test Server. See page 9 to see how to switch the app server to "Production". This will allow you to see your preexisting valves again. This information does not apply unless you have more than one valve.

Android Device Setup


(see page 1 for IOS Setup)

Based on the email address supplied to our Team, the Google Play account associated with that account will have access to the Beta-version of our FloLogic app.

Logged into the account with given access, download the latest software for the FloLogic app from the Google Play store.



After the download has completed, open the FloLogic App.




Because we are beta testing, a new account **must** be made on the Test Server.

Once the App is open, you will register for a new account. The app will already be on the Test Server.

Special Note:

If you already have an account for any existing valves in the App, *you still must register for a new account on our Test-Server.*

You may make the Login credentials the same as your original account.



FloLogic Registration!



Dear User

Thank You for registering on the FloLogic Web Application.

We still need to confirm Your identity. To do so, please press the "Confirm Indentity" below.

Confirm Indentity

Need the FloLogic App? Get it on the [Apple App Store](#) or with [Google Play](#)

After registering for a new account, confirm your identity through the confirmation email sent to the email address you registered your account with.

After confirming, navigate back to the FloLogic app and Login.



Once Finished, your phone will be prepared for the arrival and provisioning of your new Beta-Unit!

If you have the Beta Unit now, follow the steps on the “Quick Start” Guide or “Main Guide” to get your unit set-up properly.

If you’ve already installed the Beta Unit, please reference “Beta Provisioning” to set your device up with your Valve to begin testing.

Any valves that were previously monitored using the FloLogic app will not be available to access on the Test Server. See page 9 to see how to switch the app server to “Production”. This will allow you to see your preexisting valves again. This information does not apply unless you have more than one valve.

Switching Servers in the App

If there are existing system(s) previously on your FloLogic app that you do not intend to use for the BETA test, you will still need access to these values. If you do not have more than one valve, the following information does not apply.

The accounts created on our Production server are not the same accounts created on our Test server. Due to this, existing systems will have been accessed using an account on our Production server and will not be available on the Test Server (the server where Beta Testing will take place).

There are a few ways to navigate between these servers:

1. If applicable, we recommend that you use two separate devices for this. One device will deal with the newest beta-release of the app to work with the Beta-Units. The other device will be on the Production server and will access any other valves you may have.
2. If using two devices is not an option, you can download the most recent non-beta release of the FloLogic app.

IOS (Production app access)

1. Navigate to the IOS App store and find the FloLogic app through the search bar.
2. Press “Install”. This will install the last Production release of the FloLogic App.
3. After installing the version listed in the App store, the FloLogic App will now be in the Production Server.
4. Open your FloLogic app and log-in with your original, non-beta login to access your other systems.
5. When you want to access your Beta-Valve on the Test-server, reopen test flight and Install the FloLogic app version it has listed.
6. Reopen the FloLogic app after the installation and log in with your Beta log in to resume testing.


Android (Production App Access)

1. Navigate to the Google Play store on your Android device.
2. The email used to access the Beta-Version of the app must be switched to a different Google Play email address.
3. On a different Google Play account, you will be able to access the Production version of the FloLogic app.
4. After switching accounts, find the FloLogic app through the search and select “Install”.
5. After installation, the FloLogic App will now be in the Production Server.
6. Open your FloLogic app and log-in with your original, non-beta login to access your other systems.
7. To return to Beta testing, reinstall the FloLogic app on the Google Play account that was given access to the beta version of the FloLogic app.
8. Reopen the FloLogic app after the installation and log in with your beta log in to resume testing.


3. The least recommended option is switching servers within the app. The Beta-version of the app is currently only set-up to fully communicate with the Beta Z-Connect. Using this version of the app to communicate with an older Connect can cause errors we haven't investigated.

Your home page should look like the picture below.

The front page is labeled to let you know what server you are currently accessing. It should say "Test Server" right now.




From the home page, press the down-arrow at the upper left corner of the screen.



This is the Valve-Listing page. Any valves linked to this account on the Test-Server will appear here.

Next, select the “Support” Icon to access the server switch.


Click on “Select Server”.



You should see the image below.

Select the server you would like to access, then select “Save and Quit”.

The FloLogic app will close. When you open it again, it will be on the server you selected.



You must be on the Test server for Beta Testing.